

## RRK5H REMOTE OPERATION GUIDE



### LOCK BUTTON

- |   |                      |
|---|----------------------|
| • Press and release the LOCK button to LOCK DOORS | Ignition must be OFF |
|---|----------------------|



### UNLOCK BUTTON

- |   |                     |
|---|---------------------|
| • Press and release the UNLOCK button to UNLOCK DOORS                             |                     |
| • Press and release the UNLOCK button to UNLOCK DOOR                              | During Driving Mode |
| • Press and Hold the UNLOCK button for 2 SECONDS to switch to KEYLESS basic mode. | Ignition must be ON |



### PANIC BUTTON

- |   |
|---|
| • Press and hold the PANIC button for 2 SECONDS to activate CAR FINDER. |
|---|



LOCK  
PRESS TOGETHER  
PANIC

### 2nd AUXILIARY

- |   |
|---|
| • Press LOCK and PANIC buttons together to get AUX2 Output.<br>Note: Contact installer to make sure this option is enabled. |
|---|



### AUX BUTTON


- |  |                      |
|--|----------------------|
| • Press and hold the AUX button for 1-2 seconds and release for TRUNK RELEASE        |                      |
| • Press and hold the AUX button for 4-9 SECONDS and release to SILENTLY Lock Doors   | Ignition must be OFF |
| • Press and hold the AUX button for 4-9 SECONDS and release to SILENTLY Unlock Doors | Ignition must be OFF |

## VALET OVERRIDE SWITCH OPERATION

- USED FOR:**
1. Stopping horn: Turn ignition on, press and hold valet switch until horn stops.
  2. To enter/exit keyless basic mode (LED steady on): Ignition on and hold valet switch for 5 seconds.
  3. Use to program remotes: Turn ignition on, press and release valet switch 5 times, press lock buttons on each remote to be programmed, turn ignition off. Up to 4 remotes may be programmed.

**Most Common Locations (Ask installer where it is located.)**

- Inside glove compartment, driver's kick panel, behind the fuse panel access door, underneath the dashboard in front of the driver.



**REPLACEMENT REMOTE PART NUMBER: #REMOTE-6888**

**THIS IS ONLY A GUIDE**

The button operations shown are a general guide. Consult with the dealer that installed your keyless entry to confirm these remote functions.

©2011 Micro Alarm Systems, Inc. • RRK5H-Op-NOV2013.indd